

Windbreaker "Kaja"

Model 221-30

Size 36-48



PRINT THE CUT

1. Open the pattern PDF and set the control square to Page 1 with the setting "Original size" on DIN Print A4 paper (US-Letter). (Do not click on "Adjustment to page size"!))
2. Check the square – if it is 10×10 cm, print out the whole cut sheet.
3. Place all pages next to each other as indicated by the arrows and adhere them row by row along the boundary lines, then glue the rows together.
4. Compare the body measurements with the table measurements and cut out the cut parts in the appropriate size. (The overview of the cut parts is on the pattern sheet.)

Important: Instructions do not include seam allowances, unless otherwise indicated!

SUPPLIES

- 0.9–1.0 m tadel, 100% nylon, in blue, 145 cm wide
- 1.0–1.1 m tadel, 100% nylon, in white, 145 cm wide
- 1 zip, 35 cm
- 1 Fashion Zipper
- 40–50 cm elastic, 3 cm wide

OPTIONAL BERNINA ACCESSORIES

- [Edgestitch Foot #10](#)
- [Dual Feed or Walking Foot #50](#)

CUTTING THE BLUE FABRIC

Cut the paper piece of front and back parts apart along the dividing line.

- 1 2× upper front part
- 2 1× upper back part on the fold
- 3 2× short sleeve
- 4 1× collar cut on double-sided fold

Centre strip

104/107.5/111.5/115.5/119.5/123.5/129.5×5 cm, final width 2.5 cm.

CUTTING THE WHITE FABRIC

- 1 1× lower front part on the fold
- 2 1× lower back part on the fold
- 5 2× sleeve

INSTRUCTIONS

1. Close the shoulder seams. Iron in the long edge of the collar. Sew one of the long edges right side on right side along the neckline. Clip the allowances in the curves of the front and the back parts. Measure the desired width of the later visible zip and divide it in half. On the front collar edge, iron the seam allowance plus half of the measured zip width to the wrong side. Place the zip tape below and topstitch it. Sew the narrow edges of the collar together, stopping about 2 cm in front of the collar attachment seam. Place the collar inwards on the



INSTRUCTIONS

fold. Iron the long edges of the allowances inwards and pin them to the neckline. Topstitch the inner collar edge in the seam shadow from the right.

2. Close the side seams of the upper as well as the lower front and back parts. Close the centre strip to form a ring and iron it lengthwise wrong side on wrong side along the fold. Pin the open edges right side on right side to the upper part, place the lower part right side on right side on top of it and sew all layers together. Clip the seam allowances on the right and the left of the zip tape vertically down to the seam. Fold the allowances upwards and topstitch them narrowly.
3. Close the sleeve seams of the short and the standard sleeves. On the standard sleeve, leave an opening for the elastic below the fold. Pull the short sleeve over the standard sleeves, pin them together and process it as one sleeve now. Gather the top shaping and sew the sleeves into the armholes. Hem all sleeves, insert the elastic into the standard sleeves and close it in loose width to form a ring.



made to create **BERNINA**