



## Information

### Purpose

- For quilting with 1/4" rulers.
- For free-motion quilting.
- For couching in combination with the Couching Inserts.

### For your safety

Before using this accessory, please read the instruction manual at hand as well as the instruction manual of your machine carefully.



## Application

### Using the Adjustable Ruler Foot for quilting

- > Lower the feed dog.
- > Attach the slide-on table.
- > Attach the presser foot.
- > Select Straight stitch.
- > If possible, set "Needle stop down".
- > Place the fabric beneath the presser foot.
- > Lower the presser foot.
- > Adjust the height of the presser foot. To do this, turn the adjusting wheel of the presser foot until the fabric can be moved back and forth under the presser foot sole without difficulty. (Fig. 1)
- > Thread the needle.
- > Bring the bobbin thread up to the right side of the fabric. Hold the upper thread and the bobbin thread in place together.
- > Start quilting with ruler (Fig. 2) or free-motion quilting (Fig. 3). Move the fabric with your hands according to the sewing speed in order to achieve an even stitch length.



You can find further information at:  
[www.bernina.com](http://www.bernina.com)

### Tips

- > If skipped stitches occur, reduce the presser foot height or the sewing speed.
- > For an optimal sewing result, use the straight stitch plate.
- > For an optimal stitch formation, use the same thread quality and color as top and bobbin thread.